




SIM68_EVB kit_User Guide_V1.00



Document Title:	SIM68 EVB kit User Guide
Version:	1.00
Date:	2012-03-28
Status:	Release
Document Control ID:	SIM68_EVB kit_User Guide_V1.00

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCom Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2012

Contents

Contents	3
Version History	5
1. Introduction.....	6
1.1 Acronyms and abbreviation.....	6
2 SIM68 EVB Overview	7
2.1 Detailed description of SIM68-EVB.....	7
2.2 USB Interface.....	8
3. Illustration.....	9
3.1 An example of USB driver installation	9
3.2 Connecting and run	13
4. ST GPS Testing Tool	14
4.1 Port setting	14
4.2 Click to RUN.....	15
4.3 Position fixed	16
4.4 TTFF Test.....	18

Table Index

TABLE 1: ACRONYMS AND ABBREVIATIONS	6
TABLE 2: USB PIN DEFINITION	8

Figure Index

FIGURE 1: SIM68-EVB COMPONENTS FUNCTION	7
FIGURE 2: USB INTERFACE	8
FIGURE 3: USB DRIVER INSTALLATION STEP1.....	9
FIGURE 4: USB DRIVER INSTALLITION STEP2.....	10
FIGURE 5: USB DRIVER INSTALLATION STEP3.....	10
FIGURE 6: USB DRIVER INSTALLATION STEP4.....	11
FIGURE 7: USB DRIVER INSTALLITION STEP5.....	11
FIGURE 8: USB DRIVER INSTALLITION STEP6.....	12
FIGURE 9: USB DRIVER INSTALLATION STEP7.....	12
FIGURE 10: USB DRIVER INSTALLATION STEP8.....	12
FIGURE 11: USB DRIVER INSTALLATION STEP9.....	13
FIGURE 12: PORT SETTING	14
FIGURE 13: CHOOSE THE RUNNING MODE	15
FIGURE 14: CLICK TO RUN	16
FIGURE 15: POSITION FIXED.....	17
FIGURE 16: NMEA OUTPUT	18
FIGURE 17: TTFF TSET	19

Version History

Data	Version	Description of change	Author
2012-03-28	1.00	Origin	Sunshengwu

1. Introduction

This document give the usage of SIM68 EVB-Kit, user can get useful information about the SIM68 EVB quickly through this document.

This document is subject to change without notice at any time.

1.1 Acronyms and abbreviation

Table 1: Acronyms and abbreviations

DC	Direct Current
I/O	Input/Output
LED	Light Emitting Diode
SPI	Serial Peripheral Interface
USB	Universal Serial Bus
UART	Universal Asynchronous Receiver & Transmitter

2 SIM68 EVB Overview

2.1 Detailed description of SIM68-EVB

The chapter introduces the functions of each component.




Figure 1: SIM68-EVB components function

- A: USB interface, support USB communication with SIM68, and also power the SIM68-EVB.
- B: S301, Power switch, push up to power the EVB and module, push down to power off.
- C: S304, Reserved.
- D: S302, DOWNLOAD switch, push up to going into download mode.
- E: S303, sleep switch, push up to going into sleep mode, push down to wakeup from sleep mode.
- F: S201 select power source for level shift.
- G: S202, NMEA output select. Push up to choose main port, push down to choose USB port.
- H: RESET button, pressed to reset SIM68
- I: MODULE connector, insert module and TE for test
- J: DEBUG port, for debug and download

SIM68 EVB kit User Guide

Q: MAIN port, for communication

L: test point area

M: J302, the jumper of VANT which is the source of active of antenna

N: Select for receiving NEMA data from A or Q. Jump the left and middle needle is select A port, jump the middle and right needle is select Q port.

O: Select for transmitting NEMA data from A or Q. Jump the left and middle needle is select A port, jump the middle and right needle is select Q port.

2.2 USB Interface

There is one Mini-USB interface on SIM68-EVB, which is transferred to UART by a USB to UART chip CP2103 on the EVB board.. User need to install CP2103 driver in their PC first, then connect the EVB board to the PC by a USB cable, and push S301 up to power the SIM68-EVB.

Please download the latest CP2103 driver according to the PC's OS from the following link:
<http://www.silabs.com/products/mcu/pages/usbtouartbridgevcpdrivers.aspx>

Or contact SIMCom support for it.




Figure 2: USB interface

Table 2: USB pin definition

Pin	Signal	I/O	Description
1	VBUS	I	5V input
2	D-	IO	Data minus
3	D+	IO	Data plus
4、5	GND		GND

3. Illustration

User need to install CP2103 driver in their PC first before using SIM68-EVB.

Please download the latest CP2103 driver according to the PC's OS from the following link:
<http://www.silabs.com/products/mcu/pages/usbtouartbridgevcpdrivers.aspx>

Or contact SIMCom support for it.

3.1 An example of USB driver installation

Step1.exectue Setup file (CP210x_VCP_Win_XP_S2K3_Vista_7)






Figure 3: USB driver installation step1

Step2.select “next” button then “next”

**Figure 4: USB driver installation step2**

Step3. Accept the license agreement and “next”

**Figure 5: USB driver installation step3**

Step4. Choose Driver Destination Location




Figure 6: USB driver installation step4

Step5. Confirm Installation, select “Install” button




Figure 7: USB driver installation step5

Step6. Launch the CP210x VCP Driver Installer




Figure 8: USB driver installation step6

Step7. Select “Install” button




Figure 9: USB driver installation step7

Step8. Installation completed.




Figure 10: USB driver installation step8

Step9. After completing CP2103 driver installation, connect SIM68-EVB to PC by the bus cable,

and set S301 switch to VBUS, then “Silicon Labs CP210x USB to UART Bridge (COMX)” will appear in the device manager:




Figure 11: USB driver installation step9

3.2 Connecting and run

To test the SIM68 module, the following operations are needed:

1. Install CP2103 driver
2. Install GPS test tool
3. Connect the active antenna to the RF connector, and insert SIM68-TE to module connector
4. Connect the SIM68-EVB to PC with USB cable
5. Make sure that S304 is switched off, S201 is pushed up.
6. Push up the power switch of S301.
7. Push up the switch of S202 to select UART signal
8. Open GPS test tool to test

4. ST GPS Testing Tool

Please contact SIMCom to get the newest version of ST GPS Testing tool.

4.1 Port setting

In the testing configuration panel, in the “device” tab, choose NMEA Port number as the one in device manager. (Since the testing tool only support the port from 1 to 20, you may change the port number if it is bigger than 20.) Set the debug port number if you need debug output. Both the NMEA and DEBUG Baudrate are 115200. Filling the “Path” blank and it is where you save the log files.




Figure 12: Port setting

4.2 Click to RUN

In the testing tab, choose the running mode in the “test” pull-down list, COLD, WARM, HOT, TRACK24H etc.




Figure 13: Choose the Running Mode

In a TTFF test mode, you need to write down the times you want to run for the test. The Min delay and Max delay means the stopping time between each fix test, it is recommended not to change the value 15 and 40 for a reliable test result.

After setting the test mode, press the “add” button and it will appear on the right blank. Choose it and press the “OK” button, then the module will work.




Figure 14: Click to RUN

4.3 Position fixed


After position has been fixed, the GPS information can be viewed in the device NMEA WINDOW. In the middle of the window, you can see the information of each GPS singal that has been tracked. The position details(Lat, Lon, Alt etc.) are below it.



2012-03-28



If you choose the TTFF test mode in the following step, then you can choose the testing pull-down list on the top to start or stop. When pressing start, after each test a TTFF value will appear on the bottom.



Contact us:

Shanghai SIMCom Wireless Solutions Ltd

Add: SIM Technology Building A,

No. 633, Jinzhong Road, Shanghai, P. R. China 200335

Tel: +86 21 3252 3300

Fax: +86 21 3252 3020

URL: www.sim.com